





CorporateGiftPro

Thank you for choosing the CorporateGiftPro
Electric Wine Aerator and Decanter Gift Set!

COMPARTMENTS


Model No. MGS-KD-1

1. Dispense Button
2. Indicator Light
3. Optional Aeration Switch
4. Aeration Inlet
5. Spout
6. Type-C Charging Cable
7. Charging Port
8. Adjustable Tube
9. Display Stand



CHARGE THE DEVICE

- Connect the charging cable to charge the device.(adapter not included)
- During charging, the indicator light blinks to indicate normal charging.
- The indicator light turns solid when it is fully charged.
- Full device charging takes 2.5 hours.





* Low battery alert: If the indicator light blinks during use, it indicates imminent power depletion. Kindly charge it promptly.

* Only charge using UL/GS or equivalent safety-approved adapters with a 5V output voltage.

INSTALL THE DIEVICE AND DISPENSING

- Securely attach the tube to the base nozzle of the device.
- Adjust the tube to the desired length.
- Securely fasten the device onto the wine bottle.
- If you prefer wine aeration during dispensing, turn ON the optional aeration switch.
- Press and hold the button to dispense, release to stop.



TROUBLESHOOTING TIPS

Case 1: If dispensing fails, confirm secure attachment to the bottle and a tight seal on the tube.

Case 2: This device suits wine bottles with an outer bottleneck diameter under 1.38 inches and an inner diameter between 0.7 and 0.75 inches.

Case 3: For less than 2 oz of remaining wine, remove the dispenser and pour directly from the bottle to prevent splashing caused by unstable pressure.

Case 4: If wine dispensing is below normal, it may be due to low battery. Please charge it promptly.

Contact Us

Website: www.corporategiftpro.com

Email: happy@corporategiftpro.com

Text & Call: (575)414-0883

TikTok Shop: CorporateGiftPro

Amazon Store: CorporateGiftPro