



CHARGE THE DEVICE


· Connect the charging cable to charge the device. (adapter not included)

· During charging, the indicator light blinks to indicate normal charging.

· Full device charging takes 2.5 hours.

* Low battery alert: If the indicator light blinks during use, it indicates imminent power depletion. Kindly charge it promptly.



* Only charge using UL/GS or equivalent safety-approved adapters with a 5V output voltage.



INSTALL THE DEVICE AND DISPENSING

· Securely attach the tube to the base nozzle of the device.

- Adjust the tube to the desired length.
- Securely fasten the device onto the wine bottle.
- If you prefer wine aeration during dispensing, turn ON the optional aeration switch.
- Press and hold the button to dispense, release to stop.



TROUBLESHOOTING TIPS

Case 1: If dispensing fails, confirm secure attachment to the bottle and a tight seal on the tube.

Case 2: This device suits wine bottles with an outer bottleneck diameter under 1.38 inches and an inner diameter between 0.7 and 0.75 inches.

Case 3: For less than 2 oz of remaining wine, remove the dispenser and pour directly from the bottle to prevent splashing caused by unstable pressure.

Case 4: If wine dispensing is below normal, it may be due to low battery. Please charge it promptly.

Contact Us

Website: www.corporategiftpro.com

Email: happy@corporategiftpro.com

Text & Call: (575)414-0883

TikTok Shop: CorporateGiftPro

Amazon Store: CorporateGiftPro