

User Manual

Important Safety Instructions

- The instruction manual contains important operating and maintenance instructions. For your safety, please read the manual carefully before use.
- Do not hit or drop the unit.
- Do not expose the unit to vibration, direct sunlight, extreme temperatures, or humidity.
- Do not disassemble the unit by yourself.

Product information

Model: SPM-2A2U

Power Rating: 1250W (10A Max)

AC Input: 100-240V 50/60 Hz

2USB Output: 1*USB-A+1*USB C,5V3.4A Max per port

USB Power: 17W(Max) 5VTotal 3.4A

15W wireless charger

Cord Gauge & Length: 6FT

1.Control panel

1. AL1=alarm clock 1

3. DIMMER/SNOOZE /CLOCK

5. DOWN

2. AL2=alarm clock 2

4. UP

2.Power

Power failure: Install 2 AAA batteries in the battery compartment to help keep track of the time and alarm settings during a power failure or disconnection of the power cord. During battery-backup mode, the screen will go blank, but the time will continue to run and the alarms will still go off. (The clock display needs to be plugged into electricity to activate.)

Note: The charging station does not support charging function during battery backup mode.

3.Time setting

- To adjust the time, hold the **DIMMER/SNOOZE/CLOCK** button for 2 seconds
- The hour will start flashing first. Use the **UP** and **DOWN** buttons to select the desired number.
- Once you have finished adjusting the hour, press the button again to switch to minute adjustment mode. Use the **UP** and **DOWN** buttons to jump to the desired minute.
- Finally, press the **DIMMER/SNOOZE/CLOCK** button to complete the time adjustment.

4. Alarm Setting

A Set of 2 alarm clock and 1 alarm ringtone (Beeping)

- To set the alarm, long-press **AL1** to enter the alarm setting mode.
- The display will flash, and you can press **UP** or **DOWN** to select the hour.
- Press **AL1** again to confirm the selected hour and enter the minute setting state. Once the screen is flashing, use **UP** or **DOWN** to select the minute.
- Press **AL1** again to confirm the selected minute, exit the setting mode, and then short-press **AL1** again.
- **AL2** can be set the same way as **AL1**.

Note:

- A short press of the **AL1** button turns the **AL1** on or off. When the **AL1** is on, the **AL1** light is on. When the **AL1** is ringing, press the **AL1** once to stop the alarm, but the alarm remains on.
- In time setting mode, press the **UP** or **DOWN** button to select the hour and minute step by step. Long press the **UP** or **DOWN** button to quickly select the hour and minute until the button is released.
- The clock uses a 12-hour time format. When the time is set to afternoon, the PM indicator will light up, and when the time is set to morning, the AM indicator will light up.

Extend the alarm clock (nap mode)

When **AL1** is ringing, press the **DIMMER/SNOOZE/CLOCK** button to temporarily silence the alarm for the set duration (9 minutes is the default). The host will stop the current ringing tone and enter the nap mode. Under this mode, **AL1** will flash. To exit the nap mode, press **AL1** twice while the alarm is still on.

5. Dimmer

- The power-on default LED display brightness is maximum.
- In clock mode, short press the **DIMMER/SNOOZE/CLOCK** button once to set the LED brightness to 2/3 of the maximum.
- Press the button again to set the LED brightness to 1/3 of the maximum.
- Press the button once more, and the LED brightness will be 0.